

See discussions, stats, and author profiles for this publication at: <https://www.researchgate.net/publication/335601087>

Crystallographic phase and orientation mapping of ferroelectric HfO₂ thin films by transmission Kikuchi diffraction

Poster · August 2019

CITATIONS

0

READS

227

5 authors, including:



Maximilian Lederer

Fraunhofer Institute for Photonic Microsystems IPMS

49 PUBLICATIONS 192 CITATIONS

SEE PROFILE



Thomas Kämpfe

Fraunhofer Institute for Photonic Microsystems IPMS

133 PUBLICATIONS 765 CITATIONS

SEE PROFILE



Clemens Mart

Infineon Technologies

54 PUBLICATIONS 252 CITATIONS

SEE PROFILE



T. Ali

Fraunhofer Institute for Photonic Microsystems IPMS

46 PUBLICATIONS 327 CITATIONS

SEE PROFILE

Some of the authors of this publication are also working on these related projects:



MTJ, Spin torque [View project](#)



Pyroelectric effect in ferroelectric hafnium oxide [View project](#)

Crystallographic phase and orientation mapping of ferroelectric HfO₂ thin films by transmission Kikuchi diffraction

M. Lederer*¹, T. Kämpfe¹, C. Mart¹, T. Ali¹, L. Roy¹, K. Seidel¹

¹Fraunhofer IPMS, Königsbrücker Str. 178, 01099 Dresden, Germany

*e-mail: maximilian.lederer@ipms.fraunhofer.de

Abstract

Since the discovery of ferroelectricity in HfO₂ thin films [1], it obtained great research interest for the implementation into various integrated devices e.g. non-volatile memories or infrared sensors, due to its CMOS compatibility. As the ferroelectricity in HfO₂ is assigned to the orthorhombic Pca2₁ phase [2], its phase fraction and orientation have a strong influence on the ferroelectric properties of the polycrystalline thin film. Due to the similar x-ray diffraction (XRD) pattern of the tetragonal and cubic phase, XRD analysis of the orthorhombic phase is strongly limited.




Figure 1. Phase identification of HfO₂ by TKD. From the EBSD pattern contrast of each point, a quality map (a) can be constructed. By comparing the EBSD patterns with simulated patterns from given phases (b), the phase can be identified and a phase map (c) can be constructed.

Transmission Kikuchi diffraction (TKD) using a scanning electron microscope (SEM) is used for orientation mapping of nanostructured metals and is suggested to become an important technique for the characterization of nanocrystalline structures [3]. Here, we report the TKD analysis of Zr-doped HfO₂ thin films. Therefore, the measured electron diffraction of dimpled samples are transformed into the Hough space and compared with the phases of HfO₂ (see figure 1). This allows the mapping of the crystallographic phase and grain orientation which indicates a strong out-of-plane texture of the orthorhombic phase.

Acknowledgments

We received funding within the ECSEL Joint Undertaking project WAKeMeUP in collaboration with the European Union's H2020 Framework Program (H2020/2014-2020) and National Authorities, under grant agreement number 783176. Furthermore, the work was supported by D. Goran from Bruker Nano Corporation.

References

- [1] T.S. Böske, J. Müller, D. Bräuhäus, U. Schröder, and U. Böttger, *Appl. Phys. Lett.* **2011**, 99, 102903.
- [2] X. Sang, E.D. Grimley, T. Schenk, U. Schroeder, and J.M. LeBeau, *Appl. Phys. Lett.* **2015**, 106, 162905.
- [3] P.W. Trimby, *Ultramicroscopy* **2012**, 120, 16.